



# HOW TO RUN A PIPE KLENZ IN YOUR SPA

Crystal Waters Pipe Klenz has been specially formulated to thoroughly cleanse spa pipes and equipment from body fats and build ups of grease and oils that coat the inside of spa and hot tub pipe work.

All spas should be treated with Crystal Waters Pipe Klenz at least once per year, or more often depending on use. Body fats and oils eventually cause foaming in spas, as well as consume sanitisers used for the control of bacteria.

To run a pipe cleaner through your spa please follow the below steps.

1. Remove cover from spa, swim spa or hot tub
2. Make sure spa is at normal operating water level
3. Remove filter cartridges from spa
4. Add Crystal Waters Pipe Klenz at 250ml per 1,000 litres and do the following:
  - \* Turn all jets in spa to open position
  - \* Turn the water diverters to the halfway point so that there is water coming from all the jets from that diverter
  - \* Turn air venturis to off position (to left) or excessive foaming will occur
  - \* Run Boost Pumps/High Speed Jets for 2 hours then drain (spas that are run by electronic controller timeout after 20 minutes, so it will be necessary to push button a number of times to get your two hours)
  - \* Refill spa and run for 15 minutes to flush (drain) excess filter clean from pipes
5. Refill spa through filter box with fresh water. Re-install filter cartridges
6. Follow dosage instructions for setting up your spa as per your spa user guide

